

## Datum Check

- Press **MENU** key twice from any main page screen.
- Use **ROCKER** to select **SETUP**
- Press **ENTER**
- Toggle to **UNITS**, Press **ENTER**.
- Use the **ROCKER** to highlight the desired field. Press **ENTER** to select.
- Use **ROCKER** to choose the correct field and **ENTER** to select.
- Set up all fields as per image.
- Press **QUIT** to exit.

## Garmin 62 Series

Position Format  
**New Zealand TM**

Map Datum  
**WGS 84**

Map Spheroid  
**WGS 84**

To convert a 14 digit GPS GR to a 6 Digit GR for a SitRep, ignore the first 2 and the last 2 numbers.

N: 1 2 **3 4 5** 6 7

E: 9 8 **7 3 4** 2 1

6 digit GR = 345734

## Clear Tracks & Waypoints

- Press the **MENU** key twice from any main screen page.
- Use **ROCKER** to select **Tracks**.
- Press **ENTER**.
- Toggle to **Clear**, Press **ENTER**.
- Toggle to **Yes**, Press **ENTER**.
- Press **QUIT** to exit to Main Menu.
- Press the **FIND** key.
- Toggle to **Waypoints**, press **ENTER**.
- Press **MENU**.
- Toggle to **Delete**, press **ENTER**.
- Toggle to **All Symbols**, press **ENTER**.
- Toggle to **Yes**, Press **ENTER**.
- Press **QUIT** twice to exit.

## Waypoints - Create

- Press **MARK** from any page.
- Use **ROCKER** to highlight any field you want to customise.
- Press **ENTER** to select field.
- Use **ROCKER** to customise.
- Press **QUIT** to go back one step.
- Adjust all desired fields.
- Highlight **OK** & press **ENTER** to finish.

## Waypoints - Find/Go To

- Press **FIND** from any page.
- Use **ROCKER** to highlight **Waypoint**.
- Press **ENTER** to select
- Use **ROCKER** to highlight waypoint, press **ENTER**.
- Select **Go To**.